

```
Router(config) #access-list 1 permit any
Router(config) #ip nat inside source list 1 interface fa0/1 overload
Router(config) #int fa0/0
Router(config-if) #ip nat inside
Router(config-if) #exit
Router(config) #int fa0/1
Router(config-if) #ip nat outside
Router(config-if) #
```

```
C:\>ping 30.30.30.100

Pinging 30.30.30.100 with 32 bytes of data:

Reply from 30.30.30.100: bytes=32 time<lms TTL=255
Reply from 30.30.30.100: bytes=32 time<lms TTL=255
Reply from 30.30.30.100: bytes=32 time<lms TTL=255
Reply from 30.30.30.100: bytes=32 time=6ms TTL=255
Ping statistics for 30.30.30.100:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 6ms, Average = 1ms</pre>
C:\>
```

Router#show ip nat translations Router#